



2.ADJUSTABLE ANGLE METAL BRACKET



①



Installation Steps:

1. Use the screws provided with the TF to connect and secure the TF lamp assembly to the base.
2. Attach the cover.
3. Stick the spacer at the desired installation location.
4. Use screws to secure the bracket at the desired installation location.
5. Use screws to fix the product onto the bracket.

②



Installation Steps:

1. Use the screws provided with the TF to connect and secure the TF lamp assembly to the base.
2. Attach the cover.
3. Apply the 3M adhesive to the bottom of the bracket, then stick the bracket to the installation location and secure it with screws.
4. Use screws to fix the product onto the bracket.



TF SERIES BRACKETS USER GUIDE



VIOSOR LIGHT BRACKET &
ADJUSTABLE ANGLE METAL BRACKET



911Signal Technology Inc.
www.911signal.com


B08TFX100001 V1.0

1.VIOSOR LIGHT BRACKET



Installation Steps:

1. Use the screws provided with the TF to connect and secure the TF lamp assembly to the base.
2. Insert the assembled base into the back cover and secure it with screws.
3. Apply the 3M adhesive to the beveled edge of the front cover, then stick the front cover to the desired installation location.
4. Snap the entire back cover onto the front cover adhered to the glass.



Adjustable Angle up and down 15°